

Radio connections, 4-door

*) Connector in radio compartment, 1-pin

****)** Connector at power antenna, 4-pin (junction)

